





How to Import your Job on V15 Pocket 3D


1. Tap **"Data"** in the bottom menu.




2. Click on “Sites” at the top.




3. Hit “Copy”.




4. In the “From” selection, choose “USB Storage” and make sure to have a USB plugged in.




5. Choose “Internal Storage”.




6. Select **"Topcon 4K Demo"** and make sure that it is highlighted. Then click **"OK"**.




7. It should say **"File copied successfully"**.




8. You should see your newly copied site. Tap “OK”.




9. Then tap “Yes”.




10. You'll see your whole job after clicking "Yes".




11. If you have separate files, tap "Data" at the bottom then go to "Sites".




12. Then click **"Add"**.



13. Tap **"New Local Site"** then click **"Next"**.



14. Rename the file then tap "Finish".



Add New Local Site ?

Local Site Name:


4k test

Pre-load data from active local site:

- ☐ Localization
(Control Points, Projection, Geoid, mmGPS Data)
- ☐ Layers
- ☐ Quick Codes

< Back **Finish** Cancel

15. You have successfully added a site.



Sites: (Topcon 4K Demo 8-29-22) ?

Name	Modified	Size	Surfaces	Poi
test	10/16/2025 12:14:06	2.54 KB	0	
Topcon 4K Demo 8-29-22	10/21/2025 12:40:39	33.99 KB	2	

Site has been successfully added.

OK

Add... Details... Copy... Delete

Rename OK Cancel

16. Click the newly added site. Tap "OK".

Sites: (Topcon 4K Demo 8-29-22) ?

Name ^	Modified	Size	Surfaces	Poi
4k test	10/21/2025 12:41:42	2.54 KB	0	
test	10/16/2025 12:14:06	2.54 KB	0	
Topcon 4K Demo 8-29-22	10/21/2025 12:40:39	33.99 KB	2	

Add...Details...Copy...Delete

RenameOKCancel

17. Click "Yes"

Sites: (Topcon 4K Demo 8-29-22) ?

Name ^	Modified	Size	Surfaces	Poi
4k test	10/21/2025 12:41:42	2.54 KB	0	
test			0	
Topcon 4K Demo 8-29-22		33.99 KB	2	


You are about to change to a new site.
Do you want to continue?

YesNo


Add...Details...Copy...Delete

RenameOKCancel

18. Click “Data” > “Import/Export” > then click “Import”.



19. Click the “Import” selection, then start importing your job files. Select the most suitable option




20. Make sure your **"From"** and **"Folder"** selection is properly selected depending on the requirement of the project. Once done, click on the **"File"** and click **"Next"**. *(Note: Repeat steps #18 to #20 and import each file separately if you have multiple files.)*

Import

Import : Road Surfaces

From : Topcon Project (*.tp3)

Folder : USB Storage: D:/

File	Modified	Size
 Topcon 4K Demo 8-2...	08/29/2022 10:58:46	33.83 KB

Next >

Cancel

5900 NE 152nd Ave. Suite 120 Vancouver, WA 98682

Phone: (564) 274-0024 | Fax: (360) 635-4924 - Email: Support@4kequipment.com