




How To Unselect Layers on Pocket 3D


1. Tap **"Data"** then select **"Layers..."**



2. To unselect specific layers, tap on the checkmarked boxes as shown below.



3. Once you've finished deselecting layers, tap "Ok" to confirm your changes.



4. Your selected layers will now be updated.



5. To reselect layers, go back to **"Data"**, select **"Layers..."**, and check the boxes for the layers you want to enable or disable.

5900 NE 152nd Ave. Suite 120 Vancouver, WA 98682

Phone: (360) 571-2346 | Fax: (360) 635-4924 - Email: info@4equipment.com