# How to Measure in a Line on Topcon V15 Pocket 3D

1. Tap "**Tools**" in the bottom menu then click **"Measure Topo".**

2. Tap on **"Start polyline"**.

3. Then click **"Add to layer"** (You can add it to a new layer or just choose an existing one.)

4. Go to **"Options"** then select measurement count depending on how accurate you want to get

5. Go back to **"Polyline"** then tap on **"Start"**.

6. Wait for it to finish measuring.

7. You'll see **"Black dashes"** when you walk and that's where your **"Polylines"** are going.

8. Put your "Rod" down, then tap again on **"Tools"** and **"Measure Topo"**.


9. Click **"Polyline"** then click **"Next Polyline Point"**.

10. Wait for it to finish measuring.

11. Walk towards the next desired **"Polyline Point"** and you'll see **"Black dashes"**.

12. Then tap again on **"Tools"** and **"Measure Topo"**.


13. Wait for it to finish measuring.

14. You can now see the lines made.

15. If you want to end measuring, just tap on **"Tools"** then **"Measure Topo"**.

16. Click **"Polyline"** then click **"End"**.

17. Tap **"Yes"**

18. After hitting **"Yes",** it will close and make a **"Triangle"**.